

PureLiving™

Beyond Clean. Boosting Your Freshbeing.



**NATURAL
SANITIZING
AIR REFRESHER**

User Manual



[http:// www.purelivinguvc.com](http://www.purelivinguvc.com)

Table of Contents

Preface	1
Important safety instructions	2
General product information	3
Instruction for use	4
Unpacking	4
Air Refresher product description	4
Operating instruction for temperature control	5
HEPA filter replacement	6
Trouble shooting	6
Care & Maintenance	6
Product Technical Data	7
Legal Notice	7
Accessories	7
Customer Service	7
Warranty	8-9
Terms of Warranty	10-11

Attention:

A&T Unlimit Ltd. Reserves the right for final explanation of all contents in the operation and user manual.

Preface

Thank you for choosing Pureliving Air Refresher!

Please read this specification carefully before you use the product.

Any failure and losses caused by ignoring the following mentioned statement in this instruction manual are not covered by our warranty or any liability. If you have any doubt, please send an E-mail to our service department for free supply.

PureLiving™

Beyond Clean. Boosting Your Freshbeing.

PURELIVING Appliances Website: <http://www.purelivinguvc.com>

Email: service@purelivinguvc.com

Manufacturer: A&T Eco-Development Ltd.

Manufactured in China

Important Safety Instructions

PLEASE READ ALL INSTRUCTION BEFORE USING!

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- 1) Read all instructions before using this heater.
- 2) This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
- 3) Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- 4) Always unplug heater when not in use.
- 5) Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.
- 6) Do not use outdoors.
- 7) This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- 8) Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- 9) To disconnect heater, turn controls to off, then remove plug from outlet.
- 10) Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- 11) To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- 12) A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.


- 13) Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- 14) Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- 15) SAVE THESE INSTRUCTIONS

CAUTION: TO PREVENT ELECTRIC SHOCK MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

General Product Information

PURELIVING aims to provide all households with innovated cleanliness and safety products for home use through the latest Ultraviolet light technology to enhance us an enjoyable clean air for living.

Ultraviolet light represent the frequency between 200 to 400 nanometers(nm) and is invisible. The distinct bands of UV light ranges between 200nm to 280nm, which is effectively to destory microbial and kill bacteria, germs, and viruses up to 99.99% effectively.



Pureliving Air Refresher helps eliminate disease-causing bacteria, viruses, and fungi in households and reduces odors, keeping our household in a clean antiseptic air environment.

Instruction for Use


Note: Before installation, please check the accessories with the product in terms of the following content in the packing list.

- 1) Air Refresher x1 Unit
- 2) Remote Control x1 Unit
- 3) Instruction Manual with Warranty Card x1 Booklet

Unpacking

- 1) Carefully remove the Air Refresher out from the box.
- 2) Remove all plastic bag and thin film from the appliance.
- 3) Read the user manual and rating label carefully.
- 4) All packaging materials are environmental friendly and recyclable.
- 5) When disposing, please stick to the principle of environmental protection.
- 6) Do not let children play with thin film and packaging, as it may cause choke.
- 7) Please keep children away packaging materials since it may be harmful.

Air Refresher Product Description



1) On/Off Switch

1st Press Turn On, 2nd Press Turn Off.

2) Air Flow Control Level Button

Preset at level 1 showed the current flow level on the display, and additional press will go up by one level of air flow up to level 4 maximum air flow.

3) Swing Function

On/Off for Swing function.

4) Temperature Control Level Button

Current temperature showed on the display whenever Air Refresher turned on.

Each press the temperature will go up by 1°C/34°F, and cannot exceed to maximum system setup temperature at 37°C/99°F at any time.

5) Infrared Sensor for Remote Control

Please use the remote control within 3 feet (0.9m) distance point to point to the infrared sensor in between Air Refresher and the Remote Control directly.

6) Control Display



(a) (c) (b)

a) Current Flow Level.

b) Current Room Temperature/ Selected Temperature.

c) Swing Function indicator/ Operation on the Air Refresher.

Operating Instruction for temperature Control

- 1) The heating function will not operate unless the target temperature is higher than the current room temperature.
- 2) When heating function selected, heating function will automatically adjusted to the suitable air flow for safety, and Air Refresher will automatically turn off once the current temperature achieved to your selected temperature, and Air Refresher temperature sensor will keep detecting the current temperature and if the current temperature drop by 3°C/37°F, based on your selected temperature, Air Refresher will automatically turn on again.
- 3) After automatically turned off, temperature sensor will automatically detecting every 2 minutes of the current temperature, Heating function will automatically turn on once the temperature drop by 3°C/37°F based on your selected temperature.
- 4) For your safety Air Refresher are fitted with automatic cut off function, Air Refresher will automatically turn off when Air Refresher are tilt over or overheats,
- 5) Before restarting the heating function, check and clear any blockages to ensure the Air Refresher is on a solid level surface.
- 6) Air Refresher recommended to use within 20 square meters area in order to get the best performance.

Please follow the correct installation before operating the Air Refresher

- 1) Plug the power cable into the main power supplier.
- 2) Turn on the safety switch button up right on the back of Air Refresher.
- 3) Stand by mode will release a sound signal mean Air Refresher are in stand by mode.
- 4) After the stand by mode ready, you may use the front panel or remote to operate the Air Refresher.

Failure to follow the operation procedure, Air Refresher might not be working properly or damage the IC control.

HEPA Filter Replacement

- 1) Turn off the power switch on the back of the Air Refresher.
 - 2) Unscrew the screw on the back inlet cover.
 - 3) Push down and pull to release the inlet cover.
 - 4) Use the lace on the side to pull out the old HEPA filter.
 - 5) Replace the new HEPA filter and push into the filter slot.
 - 6) Push back and clip the inlet cover on the Air Refresher.
 - 7) Screw back on the back inlet cover.
 - 8) Replacement for HEPA filter (Max. 3-6 months use depending the surrounding environment.)
(Humidity, Dryness, Temperature will effect the HEPA filter performance and replacement time.)
- *Please replace HEPA filter immediately if there is a smell of burning, odor came out from the product during operation.*

Trouble Shooting


- 1) Red light will keep flashing on the button pannel, if the built in UV-C blub are not working properly or need replacement, please contact your local Pureliving authorize service center.
- 2) Air Refresher equipped with tilt sensor function, and Air Refresher will automatically shut down for any un-expect tilt during the operation procedure.

Care & Maintenance

- 1) Turn off the Air Refresher.
- 2) Unplug from the mains electricity supply.
- 3) Allow to cool for 1 to 2 hours before cleaning if the heater has been in use.
- 4) To clean, wipe with a dry or damp cloth only.
- 5) Do not use detergents or polishes to clean the Air Refresher.
- 6) To Store the Air Refresher for extended periods, please clean the Air Refresher as described above and allow dry thoroughly. Preferably store the appliance in its original box and store in a dry place away from high temperatures.
- 7) Any other service should be performed by an authorized Pureliving service representative.

For more information's, please visit: www.purelivinguv.com

Product Technical Data

	Air Refresher
Model No.	PA
Appearance	
Rated Power	Without heating 34W ; With heating 1200W
Rated Power of UV-C Bulb	1 x 5W
Measurement	28L X 16W X 50H (cm)

Legal Notice

Patent Pending

Accessories

Please contact your local retailer or check our official website at www.purelivinguv.com for accessories and re-order information's.

Customer Service

Note: Only technicians that have received professional training and have legal qualification for Air Refresher repair. And other person must not disassemble or repair the Air Refresher without permission.

When your Air Refresher has abnormal phenomena, please discontinue to use the Air Refresher and contact PURELIVING local service center or dealer for advise.

Customer Service Contact (Hong Kong): 852-2377-0788

Customer Service Email: service@purelivinguv.com

Warranty- Limited One Year Warranty

PURELIVING sell its products with the intent that they are free of defects in manufacture and workmanship for a period of one year from the date of original purchase, except as noted below. Pureliving warrants that its product will be free from defects in material and workmanship under normal use and service. This warranty extends only to customer and does not extend to Retailers.

This warranty does not cover damage caused by misuse or abuse, accident, the attachment of any unauthorized repairs or modifications, improper use of electrical power supply, loss of power, dropped product, malfunction or damage of an operating part from failure to provide manufactures recommended maintenance, transportation damage, theft neglect, vandalism, environmental condition, loss of use during period the products is at repair facility or otherwise awaiting parts or repairs, or any other conditions whatsoever that are beyond the control of PURELIVING.

The Warranty is effective only if the product is purchased and operated in the country on which product is purchased. A product that requires modifications or adoption to enable it to be operate in any other country than the country which it was designed, manufactured, approved and/or authorized, or repair of products damaged by this modifications is not covered under this warranty.

The warranty provided herein shall be the sole and exclusive warranty. There shall be no other warranties express or imply including any imply warranty of merchantability of fitness or any other obligation on the part of the company with respect to products covered by this warranty. PURELIVING shall have no liability for any incidental, consequential or special damages. In no event shall this warranty require more than the repair or replacement of any part or parts which are found to be defective within the effective period of warranty. No refund will be given. If replacement parts for defective materials are not available, PURELIVING reserves the right to make product substitutions in lieu of repair or replacement.

This warranty does not extend to the purchase of opened, used, repaired, repackaged and /or resealed products, including but not limited to sale of such products on Internet auction sites and /or sales of such products by surplus or bulk resellers. Any and all warranties or guarantees shall immediately cease and terminate as to any products or parts thereof which are repaired, replaced, altered, or modified, without the prior express and written consent of PURELIVING.

This warranty provides you with specific legal rights. You may have additional rights which may vary from country to country. Because of individual country regulations, some of the above limitations and exclusions may not apply to you.

For more information regarding our product line,
Please visit: www.purelivinguv.com



CAUTION

- Intended location of the heater is floor only.
- Heaters should always be plugged directly into a wall outlet/receptacle, and that an extension cord or relocatable power tap (outlet/power strip) should never be used.
- Heater is not to be used in wet or moist locations.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- To Reduce the Risk of Fire – keep combustible material such as furniture, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.

Terms of Warranty

- 1) This product is guaranteed by A&T Unlimit Ltd., to be free from defects in materials and workman-ship for 1 Year from the date of original purchase.
- 2) Repair service under the terms of this warranty may only be provided by A&T Unlimit Ltd. Or its authorized agents. No payment will be issued.
- 3) This guarantee excludes:
 - a) Through accident, misuse, wear and tear, neglect. Installation and/or use in manner inconsistent with technical and safety standards in a country other than the country of purchase.
 - b) Modifications for improper use of electrical power supply to use with other countries electrical standard.
 - c) Alterations or adjustments made to the equipment (whether for the purpose of making the equipment conform to the technical and safety standards enforce in another European country or otherwise).
- 4) No liability under this guarantee shall in incurred:
 - a) In the respect to damage or loss occurring during transit to or from the purchaser.
 - b) Where the serial number plate of the equipment has been removed or altered in nontransferable.

- 5) This guarantee is personal to the original purchaser and is nontransferable.
- 6) If the equipment, in respect of which claim hereunder is made, is found on examination to comply with the published specification, a test fee will be incurred.
- 7) No dealer has any authority to vary the terms of this guarantee.

We advise the purchaser to attached this guarantee card and receipt together for product service.

Pureliving aims to provide a service facility second to none.

You can help us to achieve this aim.

- 1) Keep your purchase receipt in a safe place. Warranty work cannot be carried our without this.
- 2) Should you feel that a problem has developed with your product, first consult your user manual.

To secure your standard limited warranty, please register your products online at:
www.purelivinguvc.com



Name: _____ Tel: _____

Address: _____

Email: _____

Model Number: _____

Serial Number: _____

Date of Purchase: _____

Retailer Stamp

